

**1.** Lift seat bail (1a) and slide seat forward (1b).

**2.** Lay back cushion onto seat cushion and align backstops (2a). Holding onto the bottom of the back frame, rotate back frame and slide onto backstops (2b).

**3.** Install pivot screws, with a torx T30 allen wrench, on both sides of the back frame.



If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you. (Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500) Or visit our website: [www.steelcase.com](http://www.steelcase.com)

© 2004 Steelcase Inc.  
Grand Rapids, MI 49501  
U.S.A.

Printed in U.S.A.